



GHIBLI DMX CHART

DMX channel's functions and their values (38-36-58 DMX channels):

Mode/Channel			Value	Function
St	Ba	Ex		
1	1	1		PAN Movement 8bit :
			0-255	Pan Movement
2		2		Pan Fine 16bit
			0-255	Fine control of Pan movement
3	2	3		TILT Movement 8bit :
			0-255	Tilt Movement
4		4		Tilt Fine 16bit
			0-255	Fine control of Tilt movement
5	3	5	0-225	Speed Pan/Tilt movement: max to min speed
			226-235	blackout by movement
			236-245	blackout by all wheel changing
			246-255	no function
6	4	6		Shutter, strobe:
			0-10	Shutter closed
			11-20	No function (shutter open)
			21-117	Strobe effect slow to fast
			118-126	No function (shutter open)
			127-180	Pulse-effect in sequences
			181-191	No function (shutter open)
			192-245	Random strobe effect slow to fast
246-255	No function (shutter open)			
7	5	7		Dimmer intensity:
			0-255	Intensity 0 to 100%
		8		Fine Dimmer intensity:
			0-255	Dimmer intensity fine
8	6	9		Chase Patterns:
			0-9	Open
			10-19	Chase 1
			20-29	Chase 2
			30-39	Chase 3
			40-49	Chase 4
			50-59	Chase 5
			60-69	Chase 6
			70-79	Chase 7
			80-89	Chase 8
			90-99	Chase 9
			100-109	Chase 10
			110-119	Chase 11
			120-129	Chase 12
130-139	Chase 13			
140-255	Reserved			
9	7	10		Chase Speed:
			0-125	Fast to Slow Backward
			126-130	Stop(Speed=0)
131-255	Slow to Fast Forward			
10	8	11	0-255	Chase Fade: Fade Chase
11	9	12		Zoom :
			0-255	Zoom adjustment from small to big
		13		Zoom Fine:
			0-255	Zoom adjustment Fine
12	10	14		Focus :
			0-255	Continuous adjustment from near to far
		15		Focus Fine:
			0-255	Continuous adjustment Fine
13	11	16		Auto Focus :
			0-50	Auto Focus Off
			51-100	5m
			101-150	7.5m
			151-200	10m
201-255	15m			
14	12	17		AutoFocus Fine:
			0-255	Continuous adjustment Fine
15	13	18		Color Wheel:
			0-3	Open / white
			4-7	Color 1 (CRI Filter)
			8-11	Color 2 (Congo Blue)
			12-15	Color 3 (Green)
			16-19	Color 4 (Orange)
			20-23	Color 5 (Light Blue)
			24-27	Color 6 (Red)
			28-127	Color indexing
			128-189	Forwards rainbow effect from fast to slow
			190-193	No rotation
			194-255	Backwards rainbow effect from slow to fast
		19		Color Wheel Fine :
			0-255	Color Wheel colour change to any position Fine

16	14	20	Cyan Color : Cyan (0-white, 255-100% Cyan)
		21	Cyan Color Fine : Cyan Fine
		0-255	
17	15	22	Magenta Color : Magenta (0-white, 255-100% magenta)
		23	Magenta Color Fine : Magenta Fine
		0-255	
18	16	24	Yellow Color : Yellow (0-white, 255-100% Yellow)
		25	Yellow Color Fine : Yellow Fine
		0-255	
19	17	26	CTO Color : CTO (0-white, 255-100% CTO)
		27	CTO Color Fine : CTO Fine
		0-255	
			Rotating gobos
		0-9	Open
		01/10/19	Rot. gobo 1
		20-29	Rot. gobo 2
		30-39	Rot. gobo 3
		40-49	Rot. gobo 4
		50-59	Rot. gobo 5
		60-69	Rot. gobo 6
		70-77	Rot. Gobo 7
		78-93	Gobo 1 shake slow to fast
		94-109	Gobo 2 shake slow to fast
		110-125	Gobo 3 shake slow to fast
		126-141	Gobo 4 shake slow to fast
		142-157	Gobo 5 shake slow to fast
		158-173	Gobo 6 shake slow to fast
		174-189	Gobo 7 shake slow to fast
		190-221	Gobo wheel rotation forwards from fast to slow
		222-223	No rotation
		224-255	Gobo wheel rotation f backwards from slow to fast
			Rotating gobo index,rotating gobo rotation 1:
		0-127	Gobo indexing
		128-189	Forwards gobo rotation from fast to slow
		190-193	No rotation
		194-255	Backwards gobo rotation from slow to fast
			Rotating gobo indexing Fine 1:
		0-255	Fine indexing
			Fixed Gobo2 :
		0-21	open
		22-31	Gobo 1
		32-41	Gobo 2
		42-51	Gobo 3
		52-61	Gobo 4
		62-71	Gobo 5
		72-81	Gobo 6
		82-91	Gobo 7
		92-101	Gobo 8
		102-112	Gobo 1 shake slow to fast
		113-123	Gobo 2 shake slow to fast
		124-134	Gobo 3 shake slow to fast
		135-145	Gobo 4 shake slow to fast
		146-156	Gobo 5 shake slow to fast
		157-167	Gobo 6 shake slow to fast
		168-178	Gobo 7 shake slow to fast
		179-189	Gobo 8 shake slow to fast
		190-221	Clock-wise scroll from fast to slow
		222-223	Reserved
		224-255	Counter clock-wise scroll from slow to fast
			Animation wheel:
		0-7	open
		8-127	Forwards rotation from fast to slow
		128-135	No rotation
		136-255	Backwards rotation from slow to fast
			Iris:
		0-191	Max. diameter to Min.diameter
		192-223	Pulse closing fast to slow
		224-255	Pulse opening slow to fast
			Iris Fine:
		0-255	Iris Fine
			Prism:
		0-127	Open
		128-255	3-Facet Prism
			Rotating prism index, rotating prism rotation
		0-127	Prism indexing
		128-189	Forwards prism rotation from fast to slow
		190-193	No rotation
		194-255	Backwards prism rotation from slow to fast
			Rotating prism indexing Fine :
		0-255	Fine indexing
			Frost 1:
		0-255	0-100%
			Frost 2:
		0-255	0-100%

29	27	40		Blade 1A : Open to Close
		41	0-255	Blade 1A Fine : Open to Close Fine
30	28	42	0-255	Blade 1B : Blade 1 Rotation
		43	0-255	Blade 1B Fine : Blade 1 Rotation Fine
31	29	44	0-255	Blade 2A : Open to Close
		45	0-255	Blade 2A Fine : Open to Close Fine
32	30	46	0-255	Blade 2B : Blade 2 Rotation
		47	0-255	Blade 2B Fine : Blade 2 Rotation Fine
33	31	48	0-255	Blade 3A : Open to Close
		49	0-255	Blade 3A Fine : Open to Close Fine
34	32	50	0-255	Blade 3B : Blade 3 Rotation
		51	0-255	Blade 3B Fine : Blade 3 Rotation Fine
35	33	52	0-255	Blade 4A : Open to Close
		53	0-255	Blade 4A Fine : Open to Close Fine
36	34	54	0-255	Blade 4B : Right Blade Rotation
		55	0-255	Blade 4B Fine : Right Blade Rotation Fine
37	35	56	0-255	All Blade Rotation : All Blade Rotation
		57	0-255	All Blade Rotation Fine : All Blade Rotation Fine
				LED on/off, reset, internal programs:
			0-9	Not used
			10-14	Display Off
			15-19	Display On
			20-24	Display Invert Off
			25-29	Display Invert On
			30-34	Auto fan control mode
			35-39	Stage fan control mode
			40-44	Studio fan control mode
			45-49	Silent fan control mode
			50-54	Square Dim
			55-59	Linear Dim
			60-64	1.2K
			65-69	2.4K
			70-74	16K
			75-79	unused
			80-84	All motor reset
			85-87	Pan&Tilt motor reset
			88-90	Colors motor reset
			91-93	Gobo motor reset
			94-99	Other motor reset
			100-119	Internal program 1 (scene1~8 of EEPROM)
			120-139	Internal program 2 (scene9~16 of EEPROM)
			140-159	Internal program 3 (scene17~24 of EEPROM)
			160-179	Internal program 4 (scene25~32 of EEPROM)
			180-199	Internal program 5 (scene33~40 of EEPROM)
			200-219	Internal program 6 (scene41~48 of EEPROM)
			220-239	Internal program 7 (scene49~56 of EEPROM)
			240-255	Internal program 8 (scene49~56 of EEPROM)